

Enamel Cooking & Oven Tray with Draining Rack SD7167310(KVTC-WST)

Please read this manual carefully before use and use the product correctly.

Before use:

- Check that there are no abnormalities or defects in any part of the enamel tray or chrome rack.
- Wash both parts thoroughly with warm water and dish washing detergent.

About the product:

- As the enamelware products are handmade, there may be uneven colouring, uneven paint, black spots or bubbles. This does not affect the quality of the product but is part of its unique character.
- During manufacturing, the enamel glaze may become thinner and black in the areas where the product is hung (firing needle marks) and on the edges. This is part of the product's specifications and does not pose a quality issue.
- The chromed rack is intended for draining food after cooking. It may be damaged by use in an oven or over direct heat.

▲ Handling precautions

- Never place the empty tray in a hot oven as this may cause cracks. If you have heated the pan when it is empty, wait for it to cool down naturally without adding water or anything else.
- Never leave the heat source unattended while heating.
- When using over heat or in an oven, the body of the product will become hot. Please take care to keep it out of the reach of children, especially infants, as there is a risk of burns.
- Always use oven mitts or other protection and take care when handling the hot tray.
- This product is **not compatible** with microwave ovens or induction cookers.
- Do not subject the product to strong impacts such as hitting it hard or dropping it on the floor, as this may cause cracks or damage.
- Do not suddenly immerse the tray in water while it is still hot to cool it down.

▲ Care instructions

- Wash the product with normal dish washing detergent and warm water.
- Do not use hard sponges, scrubbing pads or abrasives cleansers, as these will damage the enamel surface.
- After washing, be sure to wipe off any excess water with a dry cloth to prevent rust forming.
- Do not soak the unit in water as this may cause rust to form.
- Due to the nature of enamel, over time rusting from the edges may occur. If you wipe away moisture and dry the product after use, you can reduce the risk of rusting.
- Enamel glaze is inorganic and does not contain any ingredients that are harmful to the human body. If rust occurs, iron rust (iron oxide) is not harmful. It can be washed away with a soft sponge.

▲ Specification

Dimensions: Width 245mm x depth 200mm x height 40mm

Surface treatment/body: Enamel

Material type/body: Enamel steel plate (thickness 0.8 mm)

Country of origin/Japan

Manufacturer contact information

Hearth Designs Co., Ltd.
2-19 Rinku Minamihama, Sennan City, Osaka Prefecture, 590-0535
Tel: 072-485-3638
Fax: 072-482-6135
HP:<http://www.hearth-designs.jp>

Imported by

Hatsukoi.co.uk
22 Slait Hill, East Cranmore, Shepton
Mallet, Somerset BA4 4LL
United Kingdom
contact@hatsukoi.co.uk

EU responsible (for authorities only)

eucomply OÜ
Pärnu mnt 139b-14 11317 Tallinn,
Estonia hello@eucompliancepartner.com
+3375690241